



Model DFT045FMZ Parts List

A = Standard Equipment

O = Circuit Diagram

| Item# | Part# | Description | Q'ty Unit |
|-------|--------------|--------------------------|-----------|
| 001 | 345343-6 | PLATE G | 1 PC. |
| 002 | 853A34-6 | DFT045F NAME PLATE | 1 PC. |
| 003 | 183F88-2 | HOUSING SET | 1 SET |
| | C10 263005-3 | RUBBER PIN 6 | 2 PC. |
| | C20 931002-4 | HEX. NUT M3 | 7 PC. |
| | D10 | INC. 56 | |
| 004 | 233025-1 | COMPRESSION SPRING 2 | 1 PC. |
| 005-1 | 458136-3 | SWITCH LEVER | 1 PC. |
| 006 | 632K18-5 | SWITCH UNIT | 1 PC. |
| 007 | 620521-2 | LED CIRCUIT | 1 PC. |
| 008 | 457469-3 | F/R CHANGE LEVER | 1 PC. |
| 009 | 651082-1 | SWITCH C3JW-1B-S | 1 PC. |
| 010 | 620618-7 | CONTROLLER | 1 PC. |
| 011 | 457526-7 | CHANGE PLATE | 1 PC. |
| 012 | 457484-7 | LENS | 1 PC. |
| 014 | 620622-6 | LED CIRCUIT | 1 PC. |
| 015 | 620621-8 | BUZZER CIRCUIT | 1 PC. |
| 016 | 620623-4 | USB CIRCUIT | 1 PC. |
| 017 | 144709-5 | USB COVER COMPLETE | 1 PC. |
| 018 | 643850-6 | TERMINAL | 1 PC. |
| 019 | 853A37-0 | DFT045F SERIAL NO. LABEL | 1 PC. |
| 020 | 233930-2 | RING SPRING 9 | 1 PC. |
| 021 | 267070-4 | FLAT WASHER 10 | 1 PC. |
| 022 | 232374-3 | COMPRESSION SPRING 10A | 1 PC. |
| 023 | 161607-8 | BIT SLEEVE | 1 PC. |
| 024 | 457530-6 | LOCK NUT M28 BLACK | 1 PC. |
| 025 | 213836-0 | O-RING 22 | 1 PC. |
| 026 | 216015-9 | STEEL BALL 2.4 | 2 PC. |
| 027 | 123939-1 | CLUTCH ASSEMBLY 4M | 1 PC. |
| | D10 | INC. 28-41 | |
| 028 | 961026-6 | RETAINING RING S-10 | 1 PC. |
| 029 | 210076-1 | BALL BEARING 6800LLB | 1 PC. |
| 030 | 232375-1 | COMPRESSION SPRING 10B | 1 PC. |
| 031 | 267047-9 | FLAT WASHER 10 | 1 PC. |
| 032 | 326953-8 | LOCK NUT M12 | 1 PC. |
| 033 | 144421-7 | ADJUST RING COMPLETE | 1 |
| 034 | 253391-0 | FLAT WASHER 18 | 1 PC. |
| 035 | 326944-9 | SPINDLE M | 1 PC. |
| 036 | 232373-5 | COMPRESSION SPRING 18B | 1 PC. |
| 037 | 216024-8 | STEEL BALL 4 | 3 PC. |
| 038 | 223185-7 | CAM A | 1 PC. |
| 039 | 216024-8 | STEEL BALL 4 | 3 PC. |
| 040 | 223186-5 | CAM B | 1 PC. |
| 041 | 216001-0 | STEEL BALL 3.5 | 8 PC. |
| 042 | 123970-7 | GEAR ASSEMBLY B | 1 PC. |
| | D10 | INC. 43-51 | |
| 043 | 144424-1 | CARRIER COMPLETE B | 1 PC. |
| 044 | 211375-4 | BALL BEARING 6805LLB | 1 PC. |
| 045 | 457529-1 | GEAR CASE | 1 PC. |

| | | | |
|-----|--------------|-----------------------|-------|
| 046 | 221546-5 | INTERNAL GEAR 47 | 1 |
| 047 | 221543-1 | SPUR GEAR 13 | 3 |
| 048 | 144422-5 | SPUR GEAR 20 COMPLETE | 1 PC. |
| 049 | 221544-9 | SPUR GEAR 18 | 3 |
| 050 | 267774-8 | LOCK WASHER | 1 PC. |
| 051 | 418003-4 | MOTOR BRACKET | 1 PC. |
| 052 | 266490-9 | TAPPING SCREW PT 2X6 | 3 PC. |
| 053 | 629261-9 | STATOR | 1 PC. |
| 054 | 619440-7 | ROTOR | 1 PC. |
| 055 | 652069-6 | FLAT HEAD SCREW M3X6 | 3 PC. |
| 056 | 183F88-2 | HOUSING SET | 1 SET |
| | C10 263005-3 | RUBBER PIN 6 | 2 PC. |
| | C20 931002-4 | HEX. NUT M3 | 7 PC. |
| | D10 | INC. 3 | |
| 057 | 265095-2 | PAN HEAD SCREW M3X20 | 7 PC. |
| A01 | 661432-2 | USB CABLE | 1 PC. |
| A02 | 765027-4 | TORQUE ADJUST TOOL | 1 PC. |
| E01 | 808V39-7 | CAUTION LABEL | 1 |
| E02 | 812G70-7 | CAUTION LABEL | 1 |