



Model BO4556K Parts List

A = Standard Equipment

○ = Circuit Diagram

Fig.	Part No.	Description	Q'ty	Unit
1	265995-6	TAPPING SCREW 4X18	3	PC.
2	450071-1	TOP COVER	1	
3	265995-6	TAPPING SCREW 4X18	2	PC.
5	687123-7	STRAIN RELIEF	1	PC.
6	682569-2	CORD GUARD 8-85	1	PC.
7	664064-4	POWER SUPPLY CORD #18-2-2.0	1	PC.
8	191927-6	CARBON BRUSH CB-407	1	SET
9	643995-0	BRUSH HOLDER	2	PC.
10	654532-5	TERMINAL BLOCK 1P	1	PC.
11	651527-9	SWITCH	1	PC.
12	424039-3	SWITCH COVER	1	
13	158373-6	MOTOR HOUSING COMPLETE	1	
	C10 810330-9	CAUTION LABEL	1	
14	863715-8	NAME PLATE	1	
15	593646-4	FIELD ASS'Y 115V	1	
	C10 654069-2	RECEPTACLE	2	PC.
16	266048-4	TAPPING SCREW 4X40	2	PC.
17	210034-7	BALL BEARING 607LLB	1	PC.
18	681652-2	INSULATION WASHER	1	PC.
19	515706-2	ARMATURE ASS'Y 115V	1	
	D10	INC. 17,18,20,21		
20	267806-1	WASHER 9	1	PC.
21	211092-6	BALL BEARING 629DDW	1	PC.
22	450070-3	BEARING BOX	1	
23	265995-6	TAPPING SCREW 4X18	4	PC.
24	241671-6	FAN 63	1	
25	450069-8	FAN GUIDE	1	
26	266020-6	TAPPING SCREW 4X12	2	PC.
27	162259-8	LEVER COMPLETE	2	
28	265995-6	TAPPING SCREW 4X18	2	PC.
29	424023-8	SPONGE SLEEVE 9	4	PC.
30	213983-7	O RING 4	4	
31	318151-8	FOOT	4	PC.
32	213983-7	O RING 4	4	
33	424038-5	SPONGE 6X185X3	1	
34	450067-2	BASE	1	
35	211131-2	BALL BEARING 6001DDW	1	PC.
36	313141-6	BALANCER	1	
37	912117-6	COUNTERSUNK HEAD SCREW M4X12	1	PC.
38	213510-0	O RING 36	1	PC.
39	158324-9	PAD COMPLETE	1	

	40	266020-6	TAPPING SCREW 4X12	4	PC.
A	A01	166078-4	DUST BAG	1	
	A02	257202-1	RING 25	1	PC.
A	A03	416063-0	DUST BAG NOZZLE	1	PC.
A	A04	416064-8	DUST NOZZLE	1	PC.
A	A05	450066-4	PUNCH PLATE	1	
A	A06	824806-0	PLASTIC CARRYING CASE	1	
	C10	163455-1	LATCH	2	PC.
	C20	419360-3	HANDLE	1	PC.
	A07	805616-4	MODEL NO. LABEL	1	
A	A08	742509-3	ABRASIVE PAPER #60	1	SET
A	A09	742510-8	ABRASIVE PAPER #100	1	SET
A	A10	742511-6	ABRASIVE PAPER #150	1	SET
