



Model DML817 Parts List

Item#	Part#	Description	Q'ty
001	GM00002458	LENS	1
002	GM00002459	USB SWITCH BUTTON	1
003	GM00002460	STRAP HOOK	1
004	GM00002461	USB COVER	1
005	GM00002471	LED PCBA ASSY	1
006	GM00002472	USB PCBA ASSY	1
007	GM00002473	MAIN PCBA ASSY	1
008-1A	GM00002499	BODY ASSY BLUE	1 (DML817)
008-1B	GM00002500	BODY ASSY OLIVE	1 (ADML817)
009	GM00002468	SWITCH SPRING	1
010	GM00002469	SWITCH SPRING BRACKET	1
011	GM00002470	SWITCH ASSY	1
012	GM00001012	SCREW 3X12 PB BLACK ZN	3
A01	GM00002457	LAMP SHADE	1