



## Model LC05 Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit	
001	455252-2	FRONT COVER	1		
002	424528-8	SEAL	1	PC.	
003	187625-8	HOUSING SET	1	PC.	
	D10	INC. 20			
004	142707-3	SWITCH PLATE COMPLETE	1		
005	450522-4	LENS	1	PC.	
006	632D83-2	BATTERY	1		
007	454080-2	COVER	1	PC.	
008	620320-2	CONTROLLER	1		
009	324885-3	HANGER	1	PC.	
010	232264-0	LEAF SPRING	1	PC.	
011	424367-6	RUBBER	1	PC.	
012	454077-1	FRONT COVER JOINT	1		
013	455028-7	BUTTON	1		
014	455027-9	STOPPER	1		
015	233344-5	COMPRESSION SPRING 4	1	PC.	
016	126231-4	MOTOR ASSEMBLY	1	PC.	
017	454084-4	FAN COVER	1	PC.	
018	424320-2	RUBBER RING	1	PC.	
019	423287-1	SPONGE SHEET 70-106	1	PC.	
020	187625-8	HOUSING SET	1	PC.	
	D10	INC. 3			
021	850J66-8	LC05 NAME PLATE	1		
022	266130-9	TAPPING SCREW BIND PT 3X16	8	PC.	
023	166084-9	DUST BAG	1	PC.	
024	141088-2	VALVE STAY COMPLETE	1	PC.	
025	424094-5	PACKING	1	PC.	
026	450521-6	INLET	1	PC.	
027	423444-1	SPONGE SHEET 52-76	2	PC.	
028	268271-7	PIN 3	1	PC.	
029	233580-3	TORSION SPRING 4	1	PC.	
A01	122861-9	NOZZLE ASS'Y	1	PC.	
	C10	268208-4	PIN 3	4	PC.
	C20	451410-8	ROLLER	4	PC.
	C30	424096-1	WIPER	1	PC.
A02	194566-1	PAPER FILTER SET (5PCS/SET)	1	SET	
A03	416041-0	SASH NOZZLE (IVORY)	1	PC.	
A04	416043-6	SASH NOZZLE HOLDER (IVORY)	1	PC.	
A05	451424-7	PIPE	1	PC.	
A06	***DC1001	DC1001 BATTERY CHARGER SET	1		
E01	804C21-0	CAUTION LABEL	1		