



Model XCV02Z Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty Unit
001	265995-6	TAPPING SCREW 4X18	3 PC.
002	140642-9	FRONT COVER COMPLETE	1 PC.
003	265995-6	TAPPING SCREW 4X18	2 PC.
004	451989-9	FAN COVER	1 PC.
005	213508-7	O RING 38	1 PC.
006	452067-8	JOINT	1 PC.
007	266049-2	TAPPING SCREW 4X75	3 PC.
008	266614-7	HEX. FLANGE HEAD BOLT M5X10	1 PC.
009	240122-6	FAN 86	1 PC.
010	424332-5	SEAL RING	1 PC.
011	286238-3	CAP 19	4 PC.
012	265995-6	TAPPING SCREW 4X18	3 PC.
013	187008-2	MOTOR HOUSING SET	1 PC.
	D10	INC. 10,27	
014	267047-9	FLAT WASHER 10	1 PC.
015	424330-9	MOTOR RUBBER RING A	1 PC.
016	210059-1	BALL BEARING 6000DDW	1 PC.
017	629888-5	DC MOTOR	1 PC.
018	424331-7	MOTOR RUBBER RING B	1 PC.
019	421940-3	CAP	1 PC.
020	140463-9	SWITCH PLATE COMPLETE	1 PC.
021	631973-2	SWITCH UNIT	1 PC.
022	620036-9	CONTROLLER	1 PC.
023	643852-2	TERMINAL	1 PC.
024	854A29-2	XCV02 NAME PLATE	1
025	268092-7	PIN 4	1 PC.
026	256206-0	PIN 4	1 PC.
027	187008-2	MOTOR HOUSING SET	1 PC.
	D10	INC. 10,13	
028	259048-1	RING	1 PC.
A01	122918-6	DUSTBAG ASSEMBLY	1 PC.
A02	140456-6	HOSE COMPLETE 28-2.5	1 PC.
A03	166094-6	SHOULDER BELT	1 PC.
A04	132025-7	NOZZLE ASS'Y	1 PC.
	C10	414145-2	JOINT
A05	417766-9	FRONT CUFF 38	1 PC.