



Model XLS01T/Z Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty Unit
001	245058-4	HOSE 28-0.25	1 PC.
002	459217-6	HEAD COVER	1 PC.
003	422446-4	RUBBER CAP	2 PC.
004	699129-3	POWER SUPPLY CORD UNIT	1 PC.
005	183L77-3	MOTOR HOUSING SET	1 SET
	D10	INC. 17	
006	687261-5	STRAIN RELIEF	1 PC.
007	265995-6	TAPPING SCREW 4X18	1 PC.
008	266490-9	TAPPING SCREW PT 2X6	3 PC.
009	620B02-8	CONTROLLER B	1
010	652069-6	FLAT HEAD SCREW M3X6	3 PC.
011	629409-3	STATOR	1 PC.
012	519567-2	ROTOR ASSY	1 PC.
	D10	INC. 13-15	
013	210039-7	BALL BEARING 695DDW	1 PC.
014	210023-2	BALL BEARING 627DDW	1 PC.
015	226888-2	SPUR GEAR 19	1
016	265995-6	TAPPING SCREW 4X18	4 PC.
017	183L77-3	MOTOR HOUSING SET	1 SET
	D10	INC. 5	
018	266429-2	TAPPING SCREW 3X16	6 PC.
019	253437-2	FLAT WASHER 23	1 PC.
020	226886-6	SPUR GEAR 14	3
021	212131-5	NEEDLE CAGE 307	3 PC.
022	140J82-1	SPUR GEAR 17 COMPLETE	1
023	226890-5	INTERNAL GEAR 47	1
024	226885-8	SPUR GEAR 13	5
025	140J81-3	CARRIER COMPLETE	1
026	226889-0	INTERNAL GEAR 43	1
027	267789-5	FLAT WASHER 18	1 PC.
028	213606-7	O RING 48	1 PC.
029	459216-8	GEAR HOUSING	1 PC.
030	961052-5	RETAINING RING S-12	1 PC.
031	211150-8	BALL BEARING 6901ZZ	1 PC.
032	253746-9	FLAT WASHER 12	1 PC.
033	211131-2	BALL BEARING 6001LLU	1 PC.
034	327318-7	SPINDLE	1
035	319823-8	BEARING RETAINER 47	1
036	265995-6	TAPPING SCREW 4X18	2 PC.
037	459218-4	COVER	1 PC.
038	140L62-9	BEARING COVER COMPLETE	2 PC.
039	266901-4	TAPPING SCREW 4X14	2 PC.
040	459219-2	BRUSH STOPPER	1 PC.
041	266020-6	TAPPING SCREW 4X12	5 PC.
042	140J86-3	BRUSH B COMPLETE	1 PC.
043	140J85-5	BRUSH A COMPLETE	1 PC.
044	232510-1	LEAF SPRING	4 PC.
045	199939-3	PAD 210 SET	1 PC.
	D10	INC. 46	

046	922323-5	HEX.SOCKET HEAD BOLT M6X16	1 PC.
047	459223-1	HOSE CONNECTOR	1 PC.
048	213304-3	O RING 20	1 PC.
049	459222-3	JOINT	1 PC.
050	213393-8	O RING 23	1 PC.
051	140N60-5	PIPE A COMPLETE	1 PC.
	D10	INC. 68	
052	183L76-5	ARM SET	1 PC.
	D10	INC. 57	
053	911113-1	PAN HEAD SCREW M4X10 WITH WR	2 PC.
054	232534-7	LEAF SPRING	2 PC.
055	265A35-6	HEX. BOLT M8X17	1
056	319808-4	FRAME	1
057	183L76-5	ARM SET	1 PC.
	D10	INC. 52	
058	262561-0	SLEEVE 6	2 PC.
059	911334-5	PAN HEAD SCREW M6X20	2 PC.
060	265995-6	TAPPING SCREW 4X18	4 PC.
061	183L78-1	PIPE HOUSING SET	1 SET
	D10	INC. 65	
062	459226-5	LOCK RING	1 PC.
063	140J84-7	LOCK SLEEVE COMPLETE	1 PC.
064	140L61-1	PIPE B COMPLETE	1 PC.
	C10	459225-7	PIPE STOPPER B
065	183L78-1	PIPE HOUSING SET	1 SET
	D10	INC. 61	
066	265995-6	TAPPING SCREW 4X18	4 PC.
067	266050-7	TAPPING SCREW 4X30	3 PC.
068	459224-9	PIPE STOPPER A	1 PC.
069	459228-1	CORD HOLDER	1 PC.
070	913106-4	SET SCREW M4X8	1 PC.
071	140J83-9	INDICATOR PANEL COMPLETE	1 PC.
072	183L75-7	HANDLE SET	1 SET
	C10	263005-3	RUBBER PIN 6
	D10	INC. 88	
073	346248-3	CLAMP 24	1 PC.
074	265995-6	TAPPING SCREW 4X18	1 PC.
075	459234-6	DUST NOZZLE	1
076	459229-9	CORD COVER	1 PC.
077	265995-6	TAPPING SCREW 4X18	2 PC.
078	620796-3	DIAL CIRCUIT	1 PC.
079	459230-4	LOCK OFF BUTTON	1 PC.
080	231433-0	COMPRESSION SPRING 4	1 PC.
081	419705-5	LOCK ON BUTTON	1 PC.
082	651083-9	SWITCH C3XA-1PSPM	1 PC.
083	459231-2	SWITCH LEVER	1 PC.
084	231433-0	COMPRESSION SPRING 4	1 PC.
085	620B00-2	CONTROLLER	1
086	644809-6	TERMINAL	1 PC.
087	855W06-9	XLS01 SERIAL NO. LABEL	1
088	183L75-7	HANDLE SET	1 SET
	C10	263005-3	RUBBER PIN 6
	D10	INC. 72	
089	140F99-0	CAP COMPLETE	1 PC.
	C10	213218-6	O RING 16
	C20	818H07-8	CAP LABEL

090	855V99-0	XLS01 NAME PLATE	1
091	265995-6	TAPPING SCREW 4X18	10 PC.
092	265995-6	TAPPING SCREW 4X18	4 PC.
093	265A68-1	HEX. BOLT M8X22	1 PC.
A01	B-68557	ABRASIVE PAPER DISC 8.86-120	1 PC.
A02	783217-7	HEX. WRENCH 5	1 PC.
A03	195638-5	TOOL BAG SET	1 PC.
A04	835B53-0	INNER TRAY	1
A06	450128-8	BATTERY COVER	2 PC. (XLS01T)
A07	***DC18RC	DC18RC FAST CHARGER	1 PC. (XLS01T)
	D10	COMPO-PARTS	
A08	BL1850B	BATTERY BL1850B SET (197283-2)	2 PC. (XLS01T)